

BASECAMP™ SERIES

BUNK ROOM™ 4

Assembly Instructions


Please follow these instructions to guide you through assembly only.
For complete instructions on the recommended care and use of your tent, please refer to the User's Manual at www.msrgear.com/tents.



© 2009 Cascade Designs, Inc.
4000 First Avenue South
Seattle, WA 98134 USA
1-800-531-9531 or 1-206-505-9500

7 ATTACH INTERIOR ROOM

1. Zip open end of Bunk Room tent into any internal zippered rib of Board Room™ tent.



2 INSERT INTO TENT

1. Extend closed end into interior of tent and zip into interior zipper.

