

FAST & LIGHT® SERIES

MUTHA HUBBA™ HP

Assembly Instructions

Please follow these instructions to guide you through assembly only. For complete instructions on the recommended care and use of your tent, please refer to the User's Manual at www.msrgear.com/tents.

PACKAGE INCLUDES:

2 guy cords, 2 tensioners, 12 Needle™ stakes, 1 repair sleeve




MOUNTAIN SAFETY RESEARCH®

© 2009 Cascade Designs, Inc.
4000 First Avenue South
Seattle, WA 98134 USA

1-800-531-9531 or 1-206-505-9500


1 PREPARE TENT BODY & POLES

1. Spread tent out; stake out four corners tightly.
2. Insert poles into round hub before assembling tent.




2 ATTACH HUBBED POLES

1. Insert yellow hubbed pole tips into grommets in black corner stake loops (hubs go to sides of tent, not above doors).
2. Clip black webbing clips on tent body to yellow poles.



3 CONNECT SILVER POLES

1. Insert gray pole tips into grommets on silver stake loops.
2. Clip gray poles above black crossbars, not under, to properly secure poles.



4 ATTACH RAINFLY

1. Lay rainfly over tent and slide adjustable loop grommets under pole tips at all pole tip ends.
2. Pull out vestibules until taut and stake down.

