

**FAST & LIGHT® SERIES**

# SKINNY ONE™

## Assembly Instructions

Please follow these instructions to guide you through assembly only. For complete instructions on the recommended care and use of your tent, please refer to the User's Manual at [www.msrgear.com/tents](http://www.msrgear.com/tents).

**PACKAGE INCLUDES:**

2 guy cords, 2 tensioners, 10 Needle™ stakes, 1 repair sleeve




MOUNTAIN SAFETY RESEARCH®

© 2009 Cascade Designs, Inc.  
4000 First Avenue South  
Seattle, WA 98134 USA  
1-800-531-9531 or 1-206-505-9500


### 1 PREPARE FOR SETUP

1. Spread tent out; stake out four corners.



### 2 SETUP TENT

1. Thread 2 poles through sleeves.



### 3 STAKE OUT FRONT VESTIBULE

1. Insert pole tips into grommets in stake loops.
2. Pull out front vestibule until taut and stake down.

