

**EXPEDITION™ SERIES**

# TWIN SISTERS™

## Assembly Instructions

Please follow these instructions to guide you through assembly only. For complete instructions on the recommended care and use of your tent, please refer to the User's Manual at [www.msrgear.com/tents](http://www.msrgear.com/tents).

**PACKAGE INCLUDES:**

7 Groundhog™ stakes




MOUNTAIN SAFETY RESEARCH®

© 2009 Cascade Designs, Inc.  
4000 First Avenue South  
Seattle, WA 98134 USA

1-800-531-9531 or 1-206-505-9500


### 1 PREPARE FOR SETUP

1. With door zipped shut and vent face up, spread tent out into a large rectangle.
2. Stake out four corners; to reduce wear on door zipper, stake door end slightly loose.



### 2 INSERT TREKKING POLES

1. Set poles to a height of 48".
2. Unzip tent door and place poles vertically inside shelter with handles at peaks where seams converge. Adjust pole height if needed.



### 3 STAKE OUT TENT

1. Stake out sides.

