

# HOLLER™

## Assembly Instructions

Please follow these instructions to guide you through assembly only. For complete instructions on the recommended care and use of your tent, please refer to Owner's Manual at [www.msrgear.com/tents/ownersmanual](http://www.msrgear.com/tents/ownersmanual).

### PACKAGE INCLUDES:

8 stakes, 1 repair sleeve




MOUNTAIN SAFETY RESEARCH®

© 2011 Cascade Designs, Inc.  
4000 First Avenue South  
Seattle, WA 98134 USA

1-800-531-9531 or 1-206-505-9500


## 1 PREPARE TENT BODY & POLES

1. Spread tent out; stake four corners tightly.
2. Insert poles into round hub before assembling tent.




## 2 ATTACH HUBBED POLES

1. Insert green hubbed pole tips into green stake loop grommets at corners.
2. Attach green clips to pole along length of tent.



## 3 CONNECT GRAY POLE

1. Place gray pole under green pole and insert pole tips into grommets at gray center stake loops. Attach gray clips to gray pole.



## 4 ATTACH RAINFLY

1. Lay rainfly over tent and slide adjustable loop grommets under pole tips at all pole tip ends.
2. Attach rainfly's hook and loop tabs to main pole.
3. Pull out vestibule until taut and stake down.



**Note:** All tents require staking. Unstaked tents are susceptible to blowing away. In some conditions, additional stakes and cord will be necessary. Re-adjustment of stakes and rainfly may be necessary to keep tent tight and weatherproof. Footprints help to keep your tent clean, dry, and protected from abrasion. Following these tips will prolong the life of your tent.