



# PAPA HUBBA™ NX

## Assembly Instructions

Please follow these instructions to guide you through assembly only. For complete instructions on the recommended care and use of your tent, please refer to Owner's Manual at [www.msrgear.com/tents/ownersmanual](http://www.msrgear.com/tents/ownersmanual).


### PACKAGE INCLUDES:

Frame assembly, tent body, rainfly, 2 guy cords, 2 tensioners, 14 MSR® Mini-Groundhog™ Stakes, 1 repair sleeve

Watch video setup instructions, including Fast & Light® option, at [www.msrgear.com/PapaHubba](http://www.msrgear.com/PapaHubba)


## 1 PREPARE FOR SETUP

1. Spread tent out and stake out eight corners tightly.
2. Assemble poles.




## 2 ASSEMBLE TENT

1. Insert tips of red main poles into grommets with red webbing at the stake loops.
2. Attach red ridge pole to grommets above doors.
3. Attach all red webbing clips to poles.




## 3 ATTACH SIDE POLES

1. Place gray side poles over red poles and insert side pole tips into grommets with gray webbing at the stake loops.
2. Attach gray webbing clips to gray side poles.



## 4 ATTACH RAINFLY

1. Lay rainfly over tent, aligning rainfly door with tent door, and attach rainfly's midpoint grommets to ridge pole. Secure rainfly Velcro tabs to main poles.
2. Place rainfly's adjustable loop grommets under the main pole ends at all corners, inserting pole tips into grommets.
3. Secure any rainfly hook and loop attachments to the poles.
4. Stretch out vestibules until taut and stake down, making sure seams align with frame.



**USE TIPS:** All tents require staking; unsecured tents are susceptible to wind damage. In some conditions, additional stakes and cord may be required. Readjustment of stakes and rainfly may be necessary to keep tent tight and weatherproof. A footprint can help keep your tent clean, dry and protected from abrasion. Following these tips will prolong the life of your tent. MSR® offers a full line of accessories to secure, maintain and enhance your tent.



MOUNTAIN SAFETY RESEARCH®


© 2014 Cascade Designs, Inc.  
4000 First Avenue South  
Seattle, WA 98134 USA  
1-800-531-9531  
1-206-505-9500

# PAPA HUBBA™ NX

Fast & Light® Setup with Rainfly and MSR® Footprint (sold separately).


## 1 PREPARE FOR SETUP

1. Start by staking out the footprint with the MSR logo facing up.
2. Assemble poles.




## 2 ATTACH POLES

1. Insert the poles into the footprint's corner grommets to create the same pole structure as the standard setup.




## 3 SECURE RAINFLY

1. Secure rainfly by attaching the rainfly webbing to the pole tips using the grommets.
2. Insert ridge pole into grommets above vestibule doors on rainfly.
3. Secure any rainfly hook and loop attachments to the poles.



## 4 SECURE TENT

1. Stake out the tent's vestibules and guy out if necessary.



MOUNTAIN SAFETY RESEARCH®