

EXPEDITION SERIES

TWIN SISTERS™

Assembly Instructions

These instructions alone do not guarantee durability and safe use of this product. Read the Users Manual or go to www.msrgear.com/tents.

PACKAGE INCLUDES:

7 Needle™ stakes




MOUNTAIN SAFETY RESEARCH®

© 2008 Cascade Designs, Inc.
4000 First Avenue South
Seattle, WA 98134 USA

1-800-531-9531 or 1-206-505-9500


1 PREPARE FOR SETUP

1. With door zipped shut and vent face up, spread tent out into a large rectangle.
2. Stake out four corners; to reduce wear on door zipper, stake door end slightly loose.



2 INSERT TREKKING POLES

1. Set poles to a height of 48".
2. Unzip tent door and place poles vertically inside shelter with handles at peaks where seams converge. Adjust pole height if needed.



3 STAKE OUT TENT

1. Stake out sides.

