

**FAST & LIGHT SERIES**

# TWING™

## Assembly Instructions

These instructions alone do not guarantee durability and safe use of this product. Read the Users Manual or go to [www.msrgear.com/tents](http://www.msrgear.com/tents).

### PACKAGE INCLUDES:

2 guy cords, 2 tensioners, 6 Needle™ stakes, 1 repair sleeve




MOUNTAIN SAFETY RESEARCH®

© 2008 Cascade Designs, Inc.  
4000 First Avenue South  
Seattle, WA 98134 USA

1-800-531-9531 or 1-206-505-9500


## 1 PREPARE FOR SETUP

1. With MSR® logo showing through fly, spread out shelter into a large rectangle.
2. Shorten two pre-attached guy cords to minimum length and stake out diagonally from ends.



## 2 INSERT TREKKING POLES

1. Set poles to a height of 48".
2. Place vertically inside shelter with handles at peaks where seams converge; adjust pole height if needed.



## 3 STAKE OUT WING

1. Stake out sides.

