

NEOAIR™ TORRENT™ PUMP

Instructions

INCLUDED: Torrent Pump, 12V DC Auto Accessory Outlet Adapter.

1. Battery Cover
2. DC Power Input
3. On/Off Switch
4. Nozzle Adapter
5. Nozzle Cover Gasket
6. Air Intake
7. Auto DC Power Adaptor



POWER

Insert batteries:

Remove battery cover by pressing on small tab at base and lifting out.



Insert (4) **CR123 batteries**, aligning negative (flat) end of batteries with springs as shown.



Replace the cover, inserting upper tab first, then pressing lower end in.



Or with Auto DC Power Adaptor:

Hook your Torrent Pump up to any 12V automobile DC/accessory power outlet with the included DC power adaptor.

INFLATE MATTRESS:

Press-fit pump nozzle over **OPEN** mattress valve and turn on pump. When used properly, the Torrent Pump should inflate a Large NeoAir™ mattress in just over 1.5 min. (For mattresses with larger valves, the Nozzle Cover Gasket can be removed. Battery Life: Approx. 25 Large NeoAir inflations.) When mattress has been filled to desired firmness, spin nozzle adapter to tighten mattress valve before removing pump.

Notes:

- If you plan on storing the Torrent™ Pump for an extended period of time, remove the batteries to prevent leakage and possible damage to the pump.
- To find the best deal on CR123 batteries, search online.

COMMON PROBLEMS

LIKELY SOLUTIONS

Pump does not run.

Check battery polarity and condition.
Check adapter cord for good connection.
Ensure there is power to the car accessory outlet.

Pump runs slowly.

Check battery condition.

Warranty

- Therm-a-Rest products are warranted against defects in materials and workmanship. Electronic devices are warranted for 2 years.
- Should your Therm-a-Rest product be found defective under this warranty, Cascade Designs, at its option, will repair or replace it.
- Normal wear, misuse, alteration, abuse or taking apart of the product is not covered. If your Therm-a-Rest product has repairable damage or wear not covered by your warranty, Therm-a-Rest will complete the repairs for a reasonable fee.
- Cascade Designs will not be liable for incidental or consequential damages. Some states do not allow this exclusion or limitation of incidental or consequential damages, so the above limitations may not apply.
- Shipping charges to an Authorized Repair Center for a damaged product are not covered and are the responsibility of the customer. Return shipping charges for the repaired product will be covered.

For more information about our worldwide warranty and repair service, or to find a service center near you, please visit: thermarest.com/ServiceCenter

THERMA-REST®

www.thermarest.com

© 2014 Cascade Designs, Inc.

4000 1st Avenue South | Seattle, WA 98134

P: 800-527-1527

Limited two-year warranty | Garantie limitée de deux ans

Zwei Jahre eingeschränkte Garantie | 2 年間限定保証

P.N. 33-695