




LUXURYLite[®] COT

Assembly instructions for UltraLite Cot sizes R and L and Mesh Cot size R.


For additional languages (German, Japanese, Spanish, Italian and Dutch), or to watch video setup instructions please visit thermarest.com/cots/ultralite

COMPONENTS:

Your LuxuryLite cot includes the following parts:




INSERT SHOCK-CORDED POLES:



Place the cover on the ground, *underside* facing up. Assemble the shock-corded poles and slide them into the sleeves.


BUILD A SINGLE BOW:



Place a nylon foot on each pole using the hole on the hook-facing side of the foot. Make sure the pole is positioned on the *top* of the platform. Insert a male pole into a female pole to make a bow. For standard setup, build four single bows.

Tip: To make it easier to find the correct pole ends for assembly, lay out half-assembled poles (pole seated into one foot) so all feet face in the same direction.


BUILD A TWIST BOW:




Place a male pole and a female pole into one foot. Repeat the same process with another foot, so the two pieces are *identical*. Connect the male and female poles to create a double bow. When assembled correctly, the feet will face *opposite* directions. Build two twist bows for standard setup.

Tip: Make sure half-assembled pole pairs are fully seated in the back of foot holes. To check, tap gently with a hand or against the ground.

ASSEMBLING THE BOW FRAME:




Single Bow Installation: Stand at the end of the cover with both your feet on the shock-corded poles. Attach a single bow to one of the shock-corded poles using the hook on the nylon foot. Holding the opposite foot and the center of the pole, pull the bow away from the cover until it is possible to push down on the free foot and hook it to the shock-corded pole.



Twist Bow Installation: To attach a twist bow, make sure poles are assembled correctly with one foot facing up and the other facing down. Connect one end of the bow to a shock-corded pole using the hook on the nylon foot. Twist (rotate) the other foot 180 degrees until the hook is facing the cover. Pull the center of the bow away from the cover with one hand while pushing down with the other to hook the second foot.

STANDARD SETUP: 4 single bows, 2 twist bows


For standard setup, place single bows at both ends and in the slots three places from the ends. Place twist bows in the center locations for extra support.



Tip: You can place single or twist bows in different slots to create a setup with custom support.

LIGHTWEIGHT SETUP: 4 single bows

To assemble the cot in the minimum setup, use four single bows, placing two in the center slots and two in the slots second from the ends of the cover.



THERMA-REST[®]
thermarest.com

©2013 Cascade Designs, Inc.
4000 First Avenue South, Seattle, WA 98134 USA
1-206-505-9500 | 1-800-531-9531 P.N. 81-412